C-90L/C-92L/C-95SL Series Handing Identification Sheet



How to determine door handing

- 1. Start on outside of opening.
- 2. In what direction does the active door slide open?




 Image: Non-Section Condition
 1220 Burloak Drive, Burlington, Ontario, Canada, L7L 6B3

 T. 1-866-999-1562
 customerservice@kncrowder.com

 Condition
 Condition